

As the Ford Transit Vans become more popular, we receive questions on what is the best way to install or use a Ready2Talk PA system. Luckily the vehicle dash design is very simple to work with and so is the installation.

PA 5 Portable connection

Since the power port and AUX input are close together, connection and mounting is a snap. This picture will explain the most popular place to mount your PA 5 Portable.



PA 5 or PA 5AV installation

Step 1 Using a flat removal tool, gently remove the plate that holds the USB and AUX socket.



Step 2 Unclip the 3.5 socket assembly from the plate, you might need to insert a small blade to release the clips. **Use caution!**



Step 3 Unclip and lift off the drink tray vertically to expose the power port power connection plug.



Step 4 Drill a 1" hole in the bottom of the console and fish the wires from the PA into the console area.
NOTE Ensure that you will drill into an open space and not damage anything on the other side!!!



Step 5 Using crimp connectors, connect the red wire on the PA to the gray and the black PA wire to the black with blue stripe. Fish the PA output wire and connect to the AUX input socket. Tape the connection to make sure it never comes undone.



Step 6 Now it's time to test the operation of the PA system. Turn on the key, put the stereo into the "Sync Input" mode, set the volume to about 16 -17 and talk into the mic. Once tested, reconnect the power port plug and re-install the drink tray, then re-install the plate for the USB. Clean the back of the PA box and the underside of the console with rubbing alcohol to remove any film, let dry and install the Velcro and push firmly in place.



Step 7 Finished Here is a pic with your Ready2Talk PA system installed



We hope you found this whole procedure fairly easy!

If you have ANY questions, please give us a call. 604 644-6386
info@ready2talkpa.com www.ready2talkpa.com