

Ready2Talk

TH ISO T Harness with a PA 64

For Stereos using ISO connectors (e.g. REI VR 6200D, VR 5650, APTIV, Pana-Pacific, PP Panasonic)

Thank you for purchasing our *Ready2Talk* T Harness. It is designed to make the connection of your PA 63 or PA 64 into the factory/ISO stereo virtually plug and play.

Note: Discard the master harness and the 2 x RCA pigtailed that are supplied in the PA box, they're not needed when using a T harness.

1. Remove the stereo unit from the dash to gain access to the stereo's speaker and power plugs.
2. Unplug both plugs from the stereo and connect into the receiving sockets on the T harness.
3. Connect the plugs on the T harness into the sockets into the stereo.
4. Run the PA 64 master plug and RCA pigtailed on the T harness inside the dash to your intended PA mounting location and connect the master plug & **2 x Grey and White Wire RCA Only** to the PA 64 and set the **"Input Switch" to HIGH**. (The Green and Purple RCA are not used and must be taped)
5. Mount the PA in your desired mounting location. If the printing is upside down, remember there is an inverted printing sticker included in the box so the printing is the right way up.
6. Reinstall the stereo into the dash.
7. **Important:** The PA 64 offers variable music muting. Before you do your final test, please refer to the "PA Start Up and Initial Testing" in the PA 64 manual which explains the functionality of the "Audio Mute" knob. (The PA 63 offers only full music muting when the mic is turned on)
8. **Important:** Since the T harness connects only the stereo's front speaker output to the PA, the stereo's fader must be set to the mid position and the PA 63 or PA 64 will feed 4 x 50W equally to all speakers.
If... you want to adjust the front speaker level vs. the rear speakers, remove the top 2 x screws on the front and rear plates on the PA, then the top cover. On the right side of the PC board, using a small screwdriver gently turn down both left and right adjustment pots this will lower the front speaker output level. Test the sound level while apart to get your accurate adjustment. Once completed, replace the cover and 4 screws on the PA.
9. If you have ANY questions, please give us a call. 888 724-5351 info@ready2talk.com

Ready2Talk

TH ISO T Harness with a PA 62

For Stereos using ISO connectors (e.g. REI VR 6200D, VR 5650, APTIV, Pana-Pacific, PP Panasonic)

Thank you for purchasing our **Ready2Talk** T Harness, it's designed to make the connection of your PA 62 into the factory/OEM stereo virtually plug and play.

Note: Discard the Master Harness and the 4 x RCA Grey, White, Green and Purple RCA pigtails that are supplied in the PA 62 box, they're not needed when using a T harness.

1. Remove the required dash panels to gain access to the stereo main module.
2. Unplug only the master plugs from the stereo's main module.
3. Connect the vehicle's matching master plugs to the receiving socket on the T harness.
4. Connect the master plugs on the T harness into the socket on the stereo's main module.
5. Run the PA 62 master plug and 4 x RCA pigtails on the T harness inside the dash to your intended PA mounting location and connect the master plug and 4 x RCAs plugs to the PA.
6. Re-assemble the dash and ensure all the factory components and switches are connected **before turning on the power to test the PA**. If this is not followed you may throw a service code.
7. **Important for van installations with front speakers.**
Note: See instructions on Pg. 9 in the PA 62 manual.

Although the stereo's fader control affects the music distribution to the front and rear speakers, you might also want to control the mic volume distribution to focus on the rear speakers?

Remove the top 2 x screws on both the front and rear plates on the PA 62 then remove the top cover.

On the right side of the PC board, using a small screwdriver gently turn down the adjustment pot (typically) 1/4 to 1/2 turn. Test the sound level while apart to get your accurate adjustment. Once completed, replace the cover and 4 screws.

8. Mount the PA in your desired location. Remember the inverted printing sticker is included in the box.
9. Before you do your final test, please refer to the "PA Start Up and Initial Testing" in the manual.
10. If you have ANY questions, please give us a call. 888 724-5351 info@ready2talk.com