

# Ready2Talk


## PA 5 / PA 5 Portable Mute Adjustment Instructions

Thanks for buying and using our Ready2Talk PA 5 system. As you know, there is an AUX input socket on the front of your PA system so you can play music while on tour. Your PA 5 is factory set to cut off the music when you turn on your microphone but if you want you can adjust it to any amount from 0% to 100% muting.

Here's how... remove the 4 screws holding the case together and separate the front from back. On the PC board there are 2 adjustments. Hold the box with the wires coming out of the box on the right.

1. Mic Gain – **the mic is set at the lowest setting and DO NOT adjusted** (off by itself and not shown in this pic)
2. Muting Adjustment for the 3.5mm Front AUX input – the one closest to the bottom of the PA
  - a. Turning clockwise = more muting / less music while talking
  - b. Turning counter clockwise = less muting / more music while talking

Here is a pic of the adjustment pots on the PC Board



I hope this has worked for you? If you need any more information, please give us a call or drop us a note.