



## Connection and use instructions for the FM 1012 Wireless FM modulator in a Ford Transit Van.

The FM 1012 is a wireless FM modulator that has an internal battery, ensure it is charged before first try by using the USB to Micro USB cable included and connecting to ANY USB charger. In the Ford Transit vans, there is always a dash mounted USB socket that can be used, but is only operational when the van is turned on.

Once the FM 1012 has some charge in it, it can be used even though it's not fully charged, just check that there is at least one power bar of three showing on the screen. OR the FM 1012 can be connected to the Transit vans USB port all the time to always ensure a full charge.

Now that the FM 1012 is charged here are the steps for connection and PA operation.

1. Turn on your FM radio and find an empty space on the FM dial that doesn't have a radio station in your area... only white noise. If you travel long distances, you might find the blank frequency in one town might be used by a station in another town. If so, find a blank area on the FM dial for both towns.
2. Note the blank frequency number and pre-set it into the radios memory preset buttons. (e.g. 88.3 MHz into preset #1)
3. Turn on the FM 1012 and tune it to the same frequency number. (e.g. 88.3 MHz) You'll notice that when you turn the FM 1012 to match the exact frequency, the white noise sound on the radio will stop. This confirms that the radio has found the FM 1012.  
**NOTE... all FM radio stations in North America tune in odd numbers (88.1 – 88.3 – 88.5)**
4. Plug your Ready2Talk PA 5 Portable system into the Cigar Lighter socket for power, then connect the male 3.5mm output plug on the PA into the female 3.5mm adaptor socket on the FM 1012.
5. Ensure the Mic is connected to your PA 5 Portable and turned on.
6. Increase the radio volume and talk normally into the mic and Shazam... you'll be talking through your radio!

If you have ANY questions... just give us a call. 1 888 724-5351